

Dear valued customers, for all the clocks shipped after May 8th, 2019, you can use password for the clocks. If you don't need to use password, then you can just use the software which you can download at our website <http://www.ntpclock.com/download/> . If you want to use password, please pay special attention to the below notes:

1. We should run the software as administrator, then enter the default login password “Admin@GTC” . If we don't run as administrator, then we can't reset the password. If we forget the login password we have reset, we can restore it to default password by deleting the file “PSW.ini” under C:\Windows\System32.
2. Both the login password and Secret Key can be reset. There is no default secret key, if we want to use secret key, we can set one. The secret key can only be Arabic numerals, and the numbers of the numerals can not be more than four. If we forget the secret key we have set, then we should reset the clock to factory default setting.
3. There are two versions of software, ClockSniffer_V4_1.1_x64.exe is for 64-bit operating system; ClockSniffer_V4_1.1_x86.exe is for 32-bit operating system.

Download link of ClockSniffer_V4_1.1_x64.exe

https://drive.google.com/open?id=1NUHma_LelSilkpTPQqW5_mPrEFC3tbzw

Download link of ClockSniffer_V4_1.1_x86

https://drive.google.com/open?id=1GLKWovKHIT-cESrsOltH0t9_zpiZv2Cn

